



Adjust bearing hole diameter so that whatever bearing you choose to use can be press-fit into it.



UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN MILLIMETERS SURFACE FINISH: TOLERANCES: LINEAR: ANGULAR:		FINISH:		DEBUR AND BREAK SHARP EDGES		DO NOT SCALE DRAWING		REVISION	
	NAME	SIGNATURE	DATE			TITLE:			
DRAWN									
CHK'D									
APPV'D									
MFG									
Q.A				MATERIAL:		DWG NO.		A4	
				WEIGHT:		SCALE:1:1		SHEET 1 OF 1	

Bearing_Bracket