


This is a test for your cardboard chair
 Example method created during training

Specimen 1 to 1



	Maximum Compressive extension (mm)	Compressive load at Maximum Compressive extension (N)	Compressive strain at Maximum Compressive extension (%)	Compressive stress at Maximum Compressive extension (MPa)	Modulus (Automatic) (MPa)	Energy at Preset Point (Compressive extension: 1.9 mm) (J)	Load at Preset Point (Compressive extension: 1.9 mm) (N)	Operator Name	Specimen label	Strain rate calculation	Rate 1 (mm/min)
1	42.51521	109.70299	4.25152	0.00189	0.16760	0.04964	-36.37922	Materials Science Class			152.40000
Mean	42.51521	109.70299	4.25152	0.00189	0.16760	0.04964	-36.37922				152.40000
Standard Deviation	*****	*****	*****	*****	*****	*****	*****				*****